

2008 Nissan-Datsun Sentra L4-2.0L (MR20DE)

Vehicle > ALL Diagnostic Trouble Codes (DTC) > Testing and Inspection > P Code Charts

P0032

DTC P0031, P0032 A/F SENSOR 1 HEATER**Description****SYSTEM DESCRIPTION**

SYSTEM DESCRIPTION

| Sensor | Input Signal to ECM | ECM function | Actuator |
|--|----------------------|---|--------------------------------------|
| Camshaft position sensor (PHASE) Crankshaft position sensor (POS) | Engine speed | Air fuel ratio (A/F) sensor 1 heater control | Air fuel ratio (A/F) sensor 1 heater |
| Mass air flow sensor | Amount of intake air | | |

The ECM performs ON/OFF duty control of the A/F sensor 1 heater corresponding to the engine operating condition to keep the temperature of A/F sensor 1 element at the specified range.

CONSULT-III Reference Value in Data Monitor Mode

CONSULT-III Reference Value in Data Monitor Mode

INFOID:000000001849794

Specification data are reference values.

| MONITOR ITEM | CONDITION | SPECIFICATION |
|-----------------|---|---------------|
| A/F S1 HTR (B1) | <ul style="list-style-type: none"> Engine: After warming up, idle the engine (More than 140 seconds after starting engine) | 4 - 100% |

On Board Diagnosis Logic

On Board Diagnosis Logic

INFOID:000000001849795

| DTC No. | Trouble diagnosis name | DTC detecting condition | Possible cause |
|---------------|---|--|--|
| P0031 0031 | Air fuel ratio (A/F) sensor 1 heater control circuit low | The current amperage in the air fuel ratio (A/F) sensor 1 heater circuit is out of the normal range. [An excessively low voltage signal is sent to ECM through the air fuel ratio (A/F) sensor 1 heater.] | <ul style="list-style-type: none"> • Harness or connectors [Air fuel ratio (A/F) sensor 1 heater circuit is open or shorted.] • Air fuel ratio (A/F) sensor 1 heater |
| P0032 0032 | Air fuel ratio (A/F) sensor 1 heater control circuit high | The current amperage in the air fuel ratio (A/F) sensor 1 heater circuit is out of the normal range. [An excessively high voltage signal is sent to ECM through the air fuel ratio (A/F) sensor 1 heater.] | <ul style="list-style-type: none"> • Harness or connectors [Air fuel ratio (A/F) sensor 1 heater circuit is shorted.] • Air fuel ratio (A/F) sensor 1 heater |

DTC Confirmation Procedure

NOTE: If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least **10 seconds** before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is **11 V** at idle.

1. Start engine and run it for at least **10 seconds** at idle speed.
2. Check 1st trip DTC.
3. If 1st trip DTC is detected, go to "Diagnostic Procedure" below.

Wiring Diagram




EC-A/FH-01

Wiring Diagram

INFOID:000000001849797

EC-A/FH-01

: DETECTABLE LINE FOR DTC
 : NON-DETECTABLE LINE FOR DTC




BBWA2871E

Specification data are reference values and are measured between each terminal and ground.

Pulse signal is measured by CONSULT-III.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

| TERMI- NAL NO. | WIRE COLOR | ITEM | CONDITION | DATA (DC Voltage) |
|----------------------|---------------|---------------------|--|---|
| 3 | BR/W | A/F sensor 1 heater | [Engine is running] • Warm-up condition • Idle speed (More than 140 seconds after starting engine) | Approximately 2.9 - 8.8V★  <small>PBIA8148J</small> |
| 49 | L/R | A/F sensor 1 | [Engine is running] • Warm-up condition • Engine speed: 2,000 rpm | Approximately 1.8V Output voltage varies with air fuel ratio. |
| 53 | L/G | A/F sensor 1 | [Ignition switch: ON] | Approximately 2.2V |

★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

Diagnostic Procedure

Step 1-2

Diagnosis Procedure


INFOID:0000000001849798

1. CHECK GROUND CONNECTIONS

- Turn ignition switch OFF.
 - Loosen and retighten ground screws on the body.
Refer to [EC-140, "Ground Inspection"](#)
- ↔: Vehicle front
 - Body ground (1)


OK or NG

- OK >> GO TO 2.
- NG >> Repair or replace ground connections.



2. CHECK AIR FUEL RATIO (A/F) SENSOR 1 POWER SUPPLY CIRCUIT

- Disconnect air fuel ratio (A/F) sensor 1 harness connector (1).
 - Turn ignition switch ON.
- Air fuel ratio (A/F) sensor 1 (2)




Step 2 (Continued)-6

3. Check voltage between A/F sensor 1 terminal 4 and ground with CONSULT-III or tester.

Voltage: Battery voltage

OK or NG

- OK >> GO TO 4.
NG >> GO TO 3.



3. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E3, F2
- 10A fuse
- Harness for open or short between A/F sensor 1 and fuse

>> Repair or replace harness or connectors.

4. CHECK A/F SENSOR 1 HEATER OUTPUT SIGNAL CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminal 3 and A/F sensor 1 terminal 3.
Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 5.
NG >> Repair open circuit or short to ground or short to power in harness or connectors.

5. CHECK A/F SENSOR 1 HEATER

Refer to "[Component Inspection](#)".

OK or NG

- OK >> GO TO 6.
NG >> Replace air fuel ratio (A/F) sensor 1.

6. CHECK INTERMITTENT INCIDENT


Perform [EC-135](#).

>> **INSPECTION END**

Component Inspection

AIR FUEL RATIO (A/F) SENSOR 1 HEATER

| Terminal No. | Resistance |
|--------------|--------------------------------------|
| 3 and 4 | 1.8 - 2.44 Ω [at 25°C (77°F)] |
| 3 and 1, 2 | $\infty \Omega$ |
| 4 and 1, 2 | (Continuity should not exist) |



1. Check resistance between A/F sensor 1 terminals as follows.
2. If NG, replace air fuel ratio (A/F) sensor 1.

CAUTION:

- Discard any A/F sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new A/F sensor, clean exhaust system threads using Heated Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.