

1997 GMC Truck C 1500 Truck 2WD V8-5.7L VIN R

Vehicle > ALL Diagnostic Trouble Codes (DTC) > Testing and Inspection > P Code Charts

28	<p>Check for a short to ground in the EGR Pintle Position circuit.</p> <p>Was a problem found?</p>	—	Go to Step 29	Go to Step 36
29	<p>Repair the short to ground in the EGR Pintle Position circuit.</p> <p>Refer to Wiring Repairs.</p> <p>Is the action complete?</p>	—	Go to Step 38	—
30	<p>Using proper test adapters from Connector Test Adapter kit J 35616 , install a jumper between terminals D and C of the EGR harness connector.</p> <p>Is the Actual EGR Position near the specified value?</p>	100%	Go to Step 33	Go to Step 31
31	<p>1. Check for open in the EGR Pintle Position circuit.</p> <p>2. Check for a poor connection at the EGR Valve connector.</p> <p>Was a problem found?</p>	—	Go to Step 32	Go to Step 36
32	<p>Repair the open or poor connection in the EGR pintle position circuit.</p> <p>Refer to Wiring Repairs.</p> <p>Is the action complete?</p>	—	Go to Step 38	—
33	<p>Replace the EGR valve.</p> <p>Refer to EGR Valve Replacement.</p> <p>Is the action complete?</p>	—	Go to Step 38	—

