

2011 Volkswagen Jetta Sedan (162) L4-2.0L (CBPA)

1 - Converter box -J935- (499)

◆ E-box low, (AW0)

2 - Fresh air blower relay -J13- (449, 645)

3 - Auxiliary heater operation relay -J485- (449)

4 - Fuel pump relay -J17- (449)

4 - Engine component current supply relay -J757- (498)

4 - Auxiliary engine coolant pump relay -J496- (449)

5 - Low beam relay -J331- (53)

◆ E-box low, (AW0)

6 - Fresh air blower relay -J13- (53)

7 - Terminal 75 power supply relay 1 -J680- (53)

8 - Dual tone horn relay -J4- (449)

8 - Headlamp washer system relay -J39- (449)

9 - Terminal 50 power supply relay -J682- (643)

10 - Terminal 15 power supply relay 2 -J681- (643)

11 - Rear window defogger relay -J9- (449)

12 - Fuel pump relay 2 -J49- (449, 646)

What do these codes mean and where do I find the meaning?