





8W-18 BUS COMMUNICATIONS

Component	Page	Component	Page
Cluster	8W-18-3, 4	Module-Final Drive Control	8W-18-5, 6
Control-A/C-Heater	8W-18-3, 4	Module-Gateway	8W-18-2, 5, 6, 7
Data Link Connector	8W-18-2	Module-Hands Free	8W-18-3, 4
Electronics	8W-18-2, 3, 4, 5, 6, 7	Module-Occupant Restraint Controller	8W-18-4
Fuse 11	8W-18-2	Module-Powertrain Control	8W-18-2, 5, 6
Fuse 29	8W-18-7	Module-Sentry Key Remote Entry	8W-18-3, 4
G104	8W-18-7	Module-Totally Integrated Power	8W-18-2, 3, 4, 5, 6, 7
G201	8W-18-2	Motor/Module-Sunroof	8W-18-3, 4
Media System-Monitor/Dvd	8W-18-3, 4	Radio	8W-18-4
Module-Anti-Lock Brakes	8W-18-5, 6	Receiver-Satellite	8W-18-3, 4
Module-Electronic Overhead	8W-18-3, 4		
Module-Engine Control	8W-18-5, 6		










▼▼▼▼ POWER WAGON
 ■■■■ EXCEPT SRT



▼▼▼▼ POWER WAGON
 ■■■■ EXCEPT SRT