













*10A-Models without active speaker audio system
15A-Models with active speaker audio system







FUSE
BLOCK
(M11)

- G/R → CHIME, A/T, ASCD, ABS, TIME
A/C, A, DEF, SHIFT, THEFT,
DTRL, DEF/S
- BR → METER, SHIFT, BACKL.
ASCD, A/T, VSS, PNP/SW.
MIL, ABS, SRS, TIME,
CHARGE, DTRL, WARN
- G/W → TURN, CORNER
- OR → MIRROR, HORN,
TIME, THEFT
- LG → WIPER, TIME
- OR/B → HORN

