


HOT IN ON OR START

Under-dash
Fuse/Relay
Box



WARNING
To avoid accidental deployment and possible injury, always disconnect the driver's airbag and front passenger's airbag connectors (which automatically shorts them) before working near any SRS wiring.

CAUTION: Whenever the ignition switch is ON (II), OR has been turned OFF for less than three minutes, be careful not to bump the SRS unit; the airbags could accidentally deploy and cause damage OR injuries.

