



Allows operator to select high beam, low beam or flash to pass functions.

Indicator will light when the dimmer/flash to pass switch is put into high beam position.

