

EMISSIONS AND ELECTRONIC ENGINE CONTROL COMPONENT LOCATIONS—LATE MODEL 1.6L ENGINE

1. PCV valve
2. Evaporative emission purge control solenoid valve
3. Secondary oxygen sensor
4. Catalytic converter
5. Throttle position sensor
6. Manifold absolute pressure sensor
7. Idle air control valve
8. Primary oxygen sensor
9. Intake air temperature sensor
10. Crankshaft position sensor
11. Crankshaft speed fluctuation sensor

