

Print Date: 3/11/2017

The diagram illustrates the door lock system for a 2015 Ford Focus SE. Key components and their connections include:

- ETACS CONTROL MODULE:** Provides power to the door lock relays and receives signals from the door lock/unlock switch and the power outside mirror switch.
- PASSENGER COMPARTMENT JUNCTION BLOCK:** Distributes power from the battery to the door lock relays and the door lock/unlock switch.
- DOOR LOCK RELAY and DOOR UNLOCK RELAY:** Control the locking and unlocking of the doors.
- DOOR LOCK/UNLOCK SWITCH:** Allows manual locking and unlocking of the doors.
- POWER OUTSIDE MIRROR SWITCH:** Controls the power windows and the door lock system.
- ACTUATORS:** The door lock actuators for the left front, right front, left rear, right rear, and tailgate.
- SWITCHES:** The door lock/unlock switch and the power outside mirror switch.
- WIRING:** The diagram shows the wiring for each component, including the color of the wires and the location of the connections.