

<b>Technician</b>		<b>Date&amp;Time:</b>	2020-03-04 18:34:04
<b>Customer information</b>			
<b>Title</b>	2019 Honda CIVIC		
<b>Year</b>	2019	<b>VIN:</b>	SHHFK7H64KU211744
<b>Make</b>	Honda	<b>Lic Plate</b>	
<b>Model</b>	CIVIC	<b>Odometer Mileage</b>	
<b>Sub model</b>	USA	<b>Color</b>	
<b>Engine</b>			

### Status

Status

### Technician notes

#### Scan report

System	Status
AT	Fault  4
ABS/TCS/VSA	Fault  2
SRS	Pass   No Fault
Body electrical	Fault  2
EPS	Fault  2
Keyless access (RL)	Pass   No Fault
Integrated driver support system	Fault  10
One-push start	Fault  1
Remote slot control unit	Pass   No Fault
CAN gateway	Pass   No Fault

### DTC

System	Codes	Description	Status
AT	U0100	F-CAN malfunction (TCM - FI control module)	Permanent DTC
AT	U0038	IMA CAN malfunction (IMA CAN bus OFF)	Permanent DTC
AT	U0100	F-CAN malfunction (TCM - FI control module)	Temporary DTC
AT	U0038	IMA CAN malfunction (IMA CAN bus OFF)	Temporary DTC
ABS/TCS/VSA	U0100-00	CAN communication failure with ECM/ISU	Permanent DTC
ABS/TCS/VSA	U0402-68	TCM failure	Permanent DTC
Body electrical	U0100	Gauge control module lost communication with ENG/AT	Permanent DTC
Body electrical	U0100	BCM lost communication with ECM/PCM	Permanent DTC
EPS	U0100-00	F-CAN malfunction (EPS control unit-PCM/TCM)	Permanent DTC

EPS	U0416-68	VSA system malfunction	Permanent DTC
Integrated driver support system	C0023-F0	Brake light drive relay circuit malfunction	Permanent DTC
Integrated driver support system	U0100-F1	Lost communication with the PCM (PGM-FI system) (Multipurpose camera unit)	Permanent DTC
Integrated driver support system	B2A70-12	LDW/RDM switch signal circuit short	Permanent DTC
Integrated driver support system	U0100-00	Lost communication with the PCM (PGM-FI system)	Permanent DTC
Integrated driver support system	U0128-00	Lost communication with the electric parking brake control unit	Permanent DTC
Integrated driver support system	U0420-68	EPS control unit malfunction	Permanent DTC
Integrated driver support system	U0402-68	PCM/TCM malfunction	Permanent DTC
Integrated driver support system	C0051-54	Steering angle neutral position learning incomplete	Permanent DTC
Integrated driver support system	U0416-F8	VSA modulator-Control unit malfunction	Permanent DTC
Integrated driver support system	U0416-68	VSA brake actuator malfunction	Permanent DTC
One-push start	U0100	Power control unit lost communication with PCM	Permanent DTC
PCU	U0100	Power control unit lost communication with PCM	Permanent DTC